

GB Instruction for use
NO Bruksanvisning

POWERTEX



Mechanical Rack Jack PRJ-S2

User Manual



POWERTEX Mechanical Rack Jack PRJ-S2

Instruction for use (GB) (Original instructions)

Read and understand this instruction manual before using the product. Failure to read these instructions may result in personal injury and/or property damage. Retain this instruction manual during the whole lifespan of the product.


Product description

The POWERTEX mechanical rack jack PRJ-S2 is made from high strength steel and is available in several capacities. The lifting mechanism is well protected inside a steel housing preventing it from damages and dirt. The jack is intended to lift loads using only hand force by operating the crank handle. Brake pawls will hold the load in position when the handle is released. PRJ-S2 jacks are designed to be loaded on the top support or on the lower toe support. The jacks are intended to be used to temporarily lift the load until it can be landed safely on a stable support.

Standard applied: EN 1494

Proof load testing: Each jack has been tested 1,25 x WLL at the factory prior delivery.

Temperature range: -20°C up to +50°C.



Data

Part code	WLL (ton)	Crank force to lift full load N	Weight (kg)
16.35PRJS2015	1,5	186	13,5
16.35PRJS2030	3	250	21,2
16.35PRJS2050	5	245	28,5
16.35PRJS2100	10	392	46,8

Dimensions

WLL (ton)	A mm	B x G mm	Lift height C mm	Heel height D mm	E mm	F mm	H mm	I mm	K mm	T mm
1,5	82	100x110	600-900	60-360	55	48	225	190	163	113
3	83	130x140	730-1080	70-420	60	45	250	200	197	127
5	106	140x170	730-1080	80-430	71	68	275	239	189	127
10	124	140x170	800-1210	85-495	86	76	300	293	250	248

Static test coefficient: WLL x 1,25

Generally according to EN 1494

General instructions for safe work with jacks

Lifting operations using jacks must only be conducted by trained personnel.

Always follow national safety regulations.

Operate the equipment in accordance with the information in these operating instructions.

Check the equipment prior each usage and use only equipment being in perfect working order.

Important to use the jack on a substrate with sufficient load bearing capacity, else it could sink or topple and potentially drop the load.

Always be conscious of safety and aware of hazards when working with jacks as elevated heavy loads are involved.

Plan the lift carefully and ensure that the jack will be stable during the whole lifting operation.

Never exceed the working load limit WLL stated on the product identification plate.

Always lift smoothly and avoid shock loading as this could damage the jack.

Always lift with the load centered on the support areas.

During lifting and lowering movements always observe the movement of the load and lifting equipment.

When lifting the load with the toe support, the force transmission should be as close to the rack housing as possible.

If any problem with the equipment occur during use, the work must be immediately stopped, and the jack taken out of service for a thorough examination. Carry out necessary repairs before continuing to work!

Do not leave the load suspended without supervision.

Do not allow persons or body parts under a raised load until it has been properly supported by jack stands or other suitable supports.

Do not allow persons onboard the load being lifted.

Use only hand force to operate the handle, extensions are not allowed.

Transport the jack protected against impacts and shocks, falling over or toppling.

Keep a record of all jacks and other lifting equipment

A thorough inspection should be conducted and recorded by a competent person at least every 12-month ensuring that the jack is free from defects and that it operates perfectly.

Usage exclusions

Not intended for permanent installations

Not intended to be used on vibrating loads


Not intended for use in explosive environments.

Not intended for use in chemical or corrosive environments.

Not intended for lifting hazardous loads.

Description of parts:

- 1) Base
- 2) Lever
- 3) Upper support stand
- 4) Lower support stand
- 5) Upper ratchet pawl
- 6) Lower ratchet pawl
- 7) Axle ring



Operation

Place the jack under the load on a hard level surface. Place the jack so that the load can be firmly supported by the lower (4) or upper (3) support stand. Rotate the lever (2) clockwise by hand to lift the load and counterclockwise to lower the load. Never hold the gear rack while operating the jack as the housing will travel along the rack.

Lifting with several jacks

Lifting with 2 or more jacks simultaneously represent a high-risk operation.

There is a risk for uneven load distribution and overloading as one jack may take all the load whilst others become unloaded. This type of lifts must therefore be planned and supervised by a competent person with experience in this type of lifting.

Maintenance and inspections

Daily inspection and storage

Before each use, a visual inspection shall be made for any abnormal conditions, such as cracked welds, damage, bent, worn, loose or missing parts or illegible identification plate. Also check that the jack movement is operating smoothly. If any defect is detected or malfunction occur, the jack should be removed from service immediately and thoroughly inspected by a competent person. The jack should be thoroughly inspected immediately if it is suspected to have been subjected to abnormal loading or shock loading. Always store your jack in the fully lowered position.

Thorough inspection

At least every 12 months or shorter period if required by the working conditions a thorough inspection should be made by a competent person where the equipment is inspected for any damages such as missing parts, information plate being illegible, deformations, cracks and wear that may affect safety. Repairs needed shall be performed by an authorized customer service representative. Lubrication is needed to secure smooth function and to extend lifetime. Lubricate the gear rack regularly with heavy-duty water-resistant bearing grease and a light oil for the moveable crank house parts. The results of the thorough inspections should be recorded.

End of use/Disposal



Rack jacks shall always be sorted/scrapped as general steel scrap.
Your POWERTEX distributor will assist you with the disposal, if required.

POWERTEX Tannstangjekk PRJ-S2

Bruksanvisning (NO)

Les og forstå bruksanvisningen før du tar jekken/donkraften i bruk. Å ikke følge instruksjonene kan føre til personskade og/eller materiell skade. Oppbevar bruksanvisningen i hele produktets levetid.


Produktbeskrivelse

POWERTEX mekanisk tannstangjekk PRJ-S2 er laget av høyfast stål og er tilgjengelig med flere løftekapasiteter. Løftemekanismen er godt beskyttet inne i et stålhus som forhindrer skader og smuss. Jekken er ment å løfte laster med håndkraft ved å betjene sveivhåndtaket. Sperrehakene holder lasten på plass når håndtaket slippes. PRJ-S2 tannstangjekk er designet for å løfte med jekkens krone eller tåa. Jekken er ment til å løfte lasten midlertidig til den kan senkes ned på stabil understøtte.

Standard anvendt: EN 1494

Statisk prøvingsfaktor: Hver jekk er testet med 1,25 x WLL fra fabrikken før levering.

Temperaturområde: -20°C opp til +50°C.



Tekniske data

Artikkelnummer	WLL (tonn)	Sveivkraft for å løfte full last N	Vekt (kg)
16.35PRJS2015	1,5	186	13,5
16.35PRJS2030	3	250	21,2
16.35PRJS2050	5	245	28,5
16.35PRJS2100	10	392	46,8

Dimensjoner

WLL (tonn)	A mm	B x G mm	Løftehøyde hode C mm	Løftehøyde tå D mm	E mm	F mm	H mm	I mm	K mm	T mm
1,5	82	100x110	600-900	60-360	55	48	225	190	163	113
3	83	130x140	730-1080	70-420	60	45	250	200	197	127
5	106	140x170	730-1080	80-430	71	68	275	239	189	127
10	124	140x170	800-1210	85-495	86	76	300	293	250	248

Statisk prøvingsfaktor: WLL x 1,25

Generelt i henhold til EN 1494

Generelle instruksjoner for sikkert arbeid med jekk

Løfteoperasjoner med jekk må bare utføres av opplært personell.

Følg alltid nasjonale HMS-forskrifter.

Bruk utstyret som beskrevet i denne bruksanvisningen.

Kontroller utstyret før bruk, og bruk bare utstyr som fungerer som de skal.

Bruk jekken på et underlag med tilstrekkelig bæreevne, ellers kan den synke eller velte og potensielt miste lasten.

Vær alltid bevisst på sikkerhet og klar over farene når du arbeider med jekk, da det er involvert stor fallenergi med hevet last.

Planlegg løftet nøye og sørg for at jekken vil være stabil under hele løfteoperasjonen.

Overskrid aldri jekkens arbeidslast (WLL) som er angitt på produktets merkeskilt.

Løft alltid jevnt og unngå støtbelastning, da dette kan skade jekken.

Løft alltid med lasten sentrert i løftesalen.

Under heve- og senkebevegelser må du alltid følge med på lasten og jekken.

Når du løfter på tåa, bør lastens tyngdepunkt være så nær jekken som mulig.

Hvis det oppstår problemer med utstyret under bruk, må arbeidet stoppes umiddelbart, og jekken tas ut av drift for grundig undersøkelse. Utfør nødvendige reparasjoner før du fortsetter å jobbe!

Ikke forlat lasten hevet uten tilsyn.

Ikke la personer eller kroppsdeler få tilgang under hevet last, før jekken er avlastet med egnede støtter.

Ikke for personløft.

Bruk bare håndkraft for å betjene håndtaket, forlengelsesarm er ikke tillatt.

Transporter jekken beskyttet mot støt, fall eller velt.

Hold oversikt over alle jekk og annet løfteutstyr

En grundig inspeksjon skal utføres og dokumenteres av en sakkyndig virksomhet hver 12. måned for å sikre at jekken er fri for feil og at den fungerer som den skal.

Begrensninger for bruk

Ikke beregnet for permanente installasjoner.

Ikke beregnet for vibrerende laster.


Ikke ment for bruk i eksplosive miljøer.

Ikke beregnet for bruk i kjemiske eller etsende miljøer.

Ikke beregnet for løfting av farlige laster.

Beskrivelse av deler:

- 1) Fot/ baseplate
- 2) Sveivhåndtak
- 3) Krone (øvre anleggsflate)
- 4) Tåa (nedre anleggsflate)
- 5) Sperrehake heving
- 6) Sperrehake senking
- 7) Låsering sperrehake



Operasjon

Plasser jekken på et stabilt dekke under lasten. Plasser jekken slik at lasten kan støttes godt av den nedre (4) eller øvre (3) lastbæreren. Sveiv håndtaket (2) med håndmakt med klokken for å løfte lasten og mot klokken for å senke lasten. Hold aldri tannstangen mens du bruker jekken, da huset vil bevege seg langs stangen.

Løft med flere jekker

Løfting med 2 eller flere jekker samtidig representerer en høyrisikoooperasjon.

Det er en risiko for ujevn fordeling av lasten og overbelastning, da en jekk kan ta all lasten mens andre blir avlastet. Denne typen løft må derfor planlegges og overvåkes av en kompetent person med erfaring fra samløft.

Vedlikehold og inspeksjoner

Daglig inspeksjon og lagring

Før hver bruk skal det foretas en visuell inspeksjon for å avdekke eventuelle skader, for eksempel sprukne sveiser, deformasjoner, slitasje, løse eller manglende deler eller uleselig merkeskilt. Kontroller også at jekkfunksjonene virker. Hvis det oppdages skade eller funksjonsfeil, skal jekken tas ut av drift umiddelbart og inspiseres grundig av en kompetent person. Jekken skal inspiseres grundig hvis det mistenkes at den har blitt utsatt for overbelastning eller støtbelastning. Oppbevar alltid jekken i senket stilling.

Grundig inspeksjon


Minst hver 12. måned, eller med kortere mellomrom dersom arbeidsforholdene tilsier det, skal det foretas en grundig inspeksjon av en sakkyn-dig virksomhet der jekken inspiseres for skader, slik som manglende deler, merkeskiltet er uleselig, deformasjoner, sprekker og slitasje som kan påvirke sikkerheten. Nødvendige reparasjoner skal utføres av en fra produsenten autorisert representant. Smøring er nødvendig for å sikre jevn bevegelse og forlenge levetiden. Smør tannstangen regelmessig med vannresistent smørefett for høy belastning, og bruk en lett olje til de bevegelige delene av sveivhuset. Resultatene av de grundige inspeksjoner skal dokumenteres.

Resirkulering / avhending




Tannstangjekk skal resirkuleres som metallavfall.


Din POWERTEX-distributør vil hjelpe deg med avhending, om nødvendig.



Pos	Description
1	Jack block
2	Screw
3	Rack
4	Axle
5	Elastic pin
7	Left bracket
8	Washer
9	Nut
10	Pawl spring
11	Lower ratchet pawl
12	Upper ratchet pawl
13	Axle ring
14	Ratchet wheel
15	Ratchet washer
16	Lever
17	Lock nut
18	Screw
19	Handle sleeve
20	Washer
21	Spring
22	Spring mandril
24	Axle
25	Gear
26	Axle seat
27	Washer
29	Elastic pin

POWERTEX Rack Jack PRJ-S2 – Spare parts 3 t


Pos	Description
1	Jack block
2	Screw
3	Rack
4	Axle
5	Elastic pin
7	Left bracket
8	Washer
9	Nut
10	Pawl spring
11	Lower ratchet pawl
12	Upper ratchet pawl
13	Axle ring
14	Ratchet wheel
15	Ratchet washer
16	Lever
17	Lock nut
18	Screw
19	Handle sleeve
20	Washer
21	Spring
22	Spring mandril
24	Axle
25	Gear
26	Axle seat
27	Washer
28	Sleeve
29	Elastic pin



CertMax+

The CertMax+ system is a unique leading edge certification management system which is ideal for managing a single asset or large equipment portfolio across multiple sites. Designed by the Lifting Solutions Group, to deliver optimum asset integrity, quality assurance and traceability, the system also improves safety and risk management levels.

CertMax

Marking

The POWERTEX Mechanical Rack Jack is equipped with a RFID (Radio-Frequency IDentification) tag, which is a small electronic device, that consist of a small chip and an antenna. It provides a unique identifier for the block.

The POWERTEX Mechanical Rack Jacks are **CE** marked

Standard: EN 1494.



User Manuals

You can always find the valid and updated User Manuals on the web. The manual is updated continuously and valid only in the latest version.

NB! The English version is the Original instruction.

The manual is available as a download under the following link:
www.powertex-products.com/manuals




Product compliance and conformity

SCM Citra OY
Juvan Teollisuuskatui 25 C
02920 Espoo
Finland
www.powertex-products.com



POWERTEX



www.powertex-products.com